

**IN THE UNITED STATES  
PATENT AND TRADEMARK OFFICE**

**TITLE:**

**NMR TEACHING METHOD AND APPARATUS**

**INVENTOR:**

**JOHN V. McCLUSKY**

## **BACKGROUND OF THE INVENTION**

### **1. Field of The Invention**

Applicant's invention relates to a method and apparatus for teaching students the principles of structural analysis using nuclear magnetic resonance (NMR) spectroscopy.

### **2. Background Information**

Nuclear magnetic resonance (NMR) spectroscopy is used for the study of molecular structure through measurement of the interaction of an oscillating radio-frequency electromagnetic field with a collection of nuclei immersed in a strong external magnetic field. These nuclei are parts of the atoms that are assembled into these molecules.

Once the NMR spectrum is obtained, the determination of the unknown structure is based on three requirements indicated on the spectrum. These three requirements are integration, splitting due to spin-spin coupling, and chemical shift. Each anticipated chemical fragment is determined from the chemical shift on the spectrum. Chemically different hydrogens in a molecule do not experience the same magnetic field. Electrons shield the nucleus thereby reducing the effective magnetic field and requiring energy of a lower frequency to cause resonance. On the other hand, when electrons are withdrawn from a nucleus, the nucleus is deshielded and feels a stronger magnetic field requiring more energy (higher frequency) to cause

1 resonance. Thus, the NMR spectrum can provide information about a hydrogen's  
2 electronic environment. Generally, hydrogens bound to carbons attached to electron  
3 withdrawing groups tend to resonate at higher frequencies (more downfield, to the  
4 left of the spectrum) from TMS, tetramethylsilane, a common NMR standard. The  
5 position of where a particular hydrogen atom resonates relative to TMS is called the  
6 chemical shift.

7         Integration is the second item that can be determined from an NMR  
8 spectrum. For the integration, the area under the NMR resonance is proportional to  
9 the number of hydrogens which contribute to that resonance. In this way, by  
10 measuring or integrating the number of different NMR resonances, information  
11 concerning the relative number of chemically distinct hydrogens can be obtained.  
12 Experimentally, the integrals often appear as a line over the NMR spectrum.  
13 Integration only gives information on the relative number of different hydrogens on  
14 the represented chemical fragment, not the absolute number.

15         The last item of information that can be determined from the NMR spectrum  
16 is splitting. The spectrum provides information on how many hydrogen neighbors  
17 exist for a particular hydrogen or group of equivalent hydrogens. In general, an NMR  
18 resonance will be split into  $N + 1$  peaks where  $N$  is the number of hydrogens on the  
19 adjacent atom or atoms. If there are no hydrogens on the adjacent atoms, then the  
20 resonance will remain a single peak, a singlet. If there is one hydrogen on the  
21 adjacent atoms, the resonance will be split into two peaks of equal size to form a  
22 doublet. Two hydrogens on the adjacent atoms will split the resonance into three

1 peaks with a ratio of 1:2:1 being a triplet. If there are three hydrogens on the  
2 adjacent atoms, the resonance will split into four peaks with an area in the ratio of  
3 1:3:3:1 forming a quartet.

4 When a student is first introduced to these concepts in an organic chemistry  
5 course, he or she does not typically have difficulty determining the identity of an  
6 unknown molecule as long as the molecule remains fairly simple, such as a  
7 molecule having only a few carbons. However, as the molecules become larger and  
8 multiply branched, structural determination by the student becomes quite difficult if  
9 not impossible.

10 Every full year organic chemistry text includes a chapter or half a chapter on  
11 NMR spectroscopy. Subsequent chapters then include practice problems involving  
12 NMR interpretation. NMR in these texts is taught the same way. First the authors  
13 start with a molecule and explain its spectrum. This is done for several molecules  
14 pointing out the chemical shifts, integration and splitting patterns. Several texts  
15 point out common patterns, but most leave it to the students to figure out how to go  
16 from the spectrum to the molecule. This is a much more difficult process. In some  
17 texts, some simple rules are given such as (1) count the number of signals which is  
18 equal to the number of types of hydrogens, (2) figure out the chemical fragments  
19 from the chemical shifts, (3) and solve the problem.

20 While this can work for simple molecules it is virtually guaranteed to fail for  
21 more complex spectra. Unfortunately, there are currently no "hands-on" educational  
22 tools available to assist students with molecular structure identification from NMR

1 spectra, particularly complex spectra. The present invention satisfies this need for a  
2 "hands-on" NMR educational tool which can assist students in NMR structural  
3 analysis.

#### 4 **SUMMARY OF THE INVENTION**

5 More specifically, the present invention provides an NMR teaching method  
6 and apparatus incorporating a series of pieces that represent chemical functional  
7 groups such as methine, methylene, methyl, amine, alkene, aromatic ring, alcohol,  
8 thiol, aldehyde, ketone, and halide groups. Each piece typically has the number of  
9 sides that corresponds to the number of bonds present around the central atom.  
10 Bonds to hydrogen are preferably curved while bonding sides are flat.

11 The presence of concavities and convex tabs on the bonding sides indicates  
12 bonding of the respective piece to a mating piece that causes splitting of the NMR  
13 peak. The shape of concavities on each piece is indicative of the number of  
14 hydrogens on the respective piece while the shape of the convex tab of the  
15 respective piece is indicative of the number of hydrogens on the mating piece.

16 When presented with an NMR spectrum, a student user can select the  
17 necessary pieces of the present invention by using the chemical shift, integration,  
18 and splitting data from the spectrum. Once the pieces are selected, the student user  
19 can then assemble the pieces to determine the identity of the unknown molecule in  
20 the NMR spectrum. This tool and method can be used with not only small unknown  
21 molecules but large molecules as well, thus permitting the student user to learn  
22 NMR structural identification in a simple and relaxed manner.

## **BRIEF DESCRIPTION OF THE DRAWINGS**

Fig. 1 is a top view of the methine CH pieces of the present invention.

Fig. 2 is a top view of the methylene CH<sub>2</sub> pieces of the present invention.

Fig. 3 is a top view of the methyl pieces CH<sub>3</sub> of the present invention.

Fig. 4 is a top view of the quaternary carbon piece of the present invention.

Fig. 5 is a top view of the alcohol and thiol group pieces of the present invention.

Fig. 6 is a top view of the amine pieces of the present invention.

Fig. 7 is a top view of the alkene pieces of the present invention.

Fig. 8a is a top view of the benzene pieces of the present invention.

Fig. 8b is a top view of the aromatic pieces of the present invention.

Fig. 9 is a top view of the aldehyde pieces of the present invention.

Fig. 10 is a top view of the ketone, ether, and ester pieces of the present invention.

Fig. 11 is a top view of the halide piece of the present invention.

Fig. 12 is a top view of another embodiment of the present invention showing a base methyl piece with interchangeable tabs.

Fig. 13 is a perspective view of another embodiment of the present invention showing a base methyl piece with a single rotating tab member.

Fig. 14A is a perspective view of the preferred embodiment of the present invention used to make a first attempt at constructing a molecule.

1           Fig. 14B is a perspective view of the preferred embodiment of the present  
2 invention used to make a second attempt at constructing a molecule.

### 3 4           **DETAILED DESCRIPTION OF THE PREFERRED EMBODIMENT**

5           Figs. 1-13 illustrate various pieces that are currently available in the  
6 preferred embodiment of the present invention; however, several additional pieces  
7 are anticipated to cover additional chemical fragments. Duplicates of pieces are  
8 obviously possible in the preferred embodiment and some duplicate pieces have  
9 been included to emphasize this. In addition, mirror images of pieces are also  
10 possible as are pieces having the convex tab and concavity reversed on each  
11 respective side. The pieces can be provided with the sides in a different order such  
12 as in the case for the methine pieces. The NMR splitting side and non-splitting side  
13 can also be reversed. Some examples of this are provided, but are by no means  
14 inclusive of all possibilities.

15           Each piece of the present invention typically has the number of sides  
16 corresponding to the number of bonds present around the central atom. Bonds to  
17 hydrogen are preferably curved but can be any shape which indicates no further  
18 pieces bind to that respective side. Bonding sides are flat being either with or  
19 without both concavities and convex tabs. The presence of concavities and convex  
20 tabs on the piece indicates bonding is to be made to an atom(s) or group(s) that  
21 causes splitting of the NMR peak, whereas a piece not having concavities and  
22 convex tabs is indicative of bonding to an atom(s) or group(s) that does not cause

1 splitting. The shape of the concavities indicates the number of splitting hydrogens  
2 on that chosen piece, while the shape of the convex tabs indicates the number of  
3 hydrogens on the piece to which the chosen piece is to be bonded. All convex tabs  
4 interlock with the respective concavities present on the adjoining piece. No convex  
5 tabs or concavities are present on the curved hydrogen sides. Each side of the  
6 pieces is the same length unless otherwise indicated.

7 While the preferred embodiment discusses the use of concavities and convex  
8 tabs, any design can be utilized in place of the concavities and convex tabs as long  
9 as the substitute design for the concavities represents the number of splitting  
10 hydrogens on the chosen piece and the substitute design for the convex tabs  
11 represents the number of hydrogens on the piece to which the chosen piece is to be  
12 bonded. In this case, the design can be color, letters, numbers, or an ornamental  
13 pattern either written/typed/drawn on the pieces or as a cutout on the pieces, such  
14 as, but not limited to curves or magnetic fields.

15 Fig. 1 shows a top view of the methine CH pieces 102-150 of the present  
16 invention. These pieces have three bonding sides 152 and one curved hydrogen  
17 side 154. One piece 102 is present without concavities and convex tabs and would  
18 be bonded to only an atom(s) or group(s) that does not cause observable splitting of  
19 the NMR peak. The remaining pieces 103-150 contain concavities and convex  
20 tabs. Table 1 illustrates the number of variations possible for the methine pieces



1 103-150.

Piece Number	Number of Flat Sides with No Tabs	Number of Sides with Methine Convex Tab	Number of Sides with Methylene Convex Tab	Number of Sides with Methyl Convex Tab
102	3	0	0	0
107	2	1	0	0
112	2	0	1	0
110	2	0	0	1
150/146	1	2	0	0
116/120	1	0	2	0
124/122	1	0	0	2
136/142	1	1	1	0
138/130	1	1	0	1
126/104	1	0	1	1
103	0	3	0	0
118	0	0	3	0
105	0	0	0	3
128	0	1	1	1
148	0	2	1	0
144	0	2	0	1
134	0	1	2	0
132/140	0	1	0	2
106/108	0	0	1	2
114	0	0	2	1

2

3 Table 1: Methine Pieces

4        There is only one type of concavity 156 present on these pieces 103-150  
5 since the concavity represents the number of splitting hydrogens on these pieces  
6 103-150. The concavity 156 present on pieces 103-150 has preferably three flat  
7 inset sides generally in the shape of a square; however, any shape can be used as  
8 long as it is consistent on all methine pieces 103-150 and the convex tabs on all  
9 mating pieces.

1           The convex tabs on pieces 103-150 vary depending on the atom(s) or  
2 group(s) to which the pieces 103-150 can be bound. Where pieces 103-150 are to  
3 be bound to a mating piece representing a group having one hydrogen, such as  
4 another methine piece, the convex tab 158 will preferably have three flat sides  
5 generally in the shape of a square; however, any shape can be used as long as it is  
6 consistent for the concavity of the mating piece. Pieces 103, 107, and 128-150  
7 are capable of being bound to a mating piece representing a group having one  
8 hydrogen, such as another methine piece 103-150. Pieces 107 and 128-142 are  
9 capable of binding to only one mating piece representing a group having one  
10 hydrogen; however, pieces 144-150 are capable of binding to two mating pieces  
11 representing a group having one hydrogen. Piece 103 can bind three mating pieces  
12 representing a group having one hydrogen.

13           Where pieces 103-150 are to be bound to a mating piece representing a  
14 group having two hydrogens, such as a methylene  $\text{CH}_2$  piece, the convex tab 160 is  
15 preferably shaped as an equilateral triangle, but can be any shape as long as it is  
16 consistent for the concavity of the mating piece. Pieces 104, 106, 108, 112, 114,  
17 116, 118, 120, 126, 128, 134, 136, 142, and 148 all have convex tabs 160 and  
18 are capable of binding to at least one mating piece representing a group having two  
19 hydrogens. Pieces 104, 106, 108, 112, 126, 128, 136, 142 and 148 are  
20 capable of binding to only one mating piece representing a group having two  
21 hydrogens. Pieces 114, 116, 120, and 134 can bind to as many as two mating

1 pieces representing a group having two hydrogens while piece 118 can bind to three  
2 mating pieces representing a group having two hydrogens.

3 Pieces 103-150 can also be bound to a mating piece representing a group  
4 having three hydrogens, such as a methyl  $\text{CH}_3$  piece. Where a piece 103-150 is  
5 bound to a mating piece representing a group having three hydrogens, the convex  
6 tab 162 is preferably shaped as a diamond; however, any shape can be used as  
7 long as it is consistent with the concavity of the mating piece. Pieces 104, 105,  
8 106, 108, 110, 114, 122, 124, 126, 128, 130, 132, 138, 140, and 144 have  
9 convex tabs 162 that can bind to mating pieces representing a group having three  
10 hydrogens. Pieces 104, 110, 114, 126, 128, 130, 138, and 144 can bind to one  
11 mating piece representing a group having three hydrogens while pieces 106, 108,  
12 122, 124, 132, and 140 are capable of binding to as many as two mating pieces  
13 representing a group having three hydrogens. Piece 105 can bind to three mating  
14 pieces representing a group having three hydrogens.

15 Fig. 2 is a top view of the methylene  $\text{CH}_2$  pieces 164 –200 of the present  
16 invention. These pieces have two bonding sides 202 and two curved hydrogen  
17 sides 204. One piece 164 is present without concavities and convex tabs and can  
18 be bonded to an atom(s) or group(s) that does not cause observable splitting of the  
19 NMR peak. The remaining pieces 165-200 contain concavities and convex tabs.  
20 Table 2 illustrates the number of variations possible for the methylene pieces 165-  
21 200.

Piece Number	Number of Flat Sides with No Tabs	Number of Sides with Methine Convex Tab	Number of Sides with Methylene Convex Tab	Number of Sides with Methyl Convex Tab
164	2	0	0	0
174	1	1	0	0
180/198	1	0	1	0
178/172/170	1	0	0	1
186/184	0	2	0	0
166/196/168	0	0	2	0
165	0	0	0	2
176/182	0	1	1	0
188/200	0	1	0	1
192/190/194	0	0	1	1

Table 2: Methylene Pieces

There is only one type of concavity 206 present on methylene pieces 165-200. This concavity 206 is preferably in the shape of an equilateral triangle; however, any shape can be used as long as it is consistent on all methylene pieces 165-200 and the convex tabs on all mating pieces.

The convex tabs on pieces 165-200 vary depending on the atom(s) or group(s) to which they are bound. The convex tab 208 will preferably have three flat sides generally in the shape of a square where pieces 165-200 are bound to a mating piece representing a group having one hydrogen, such as a methine piece. However, the shape of convex tab 208 can vary as long as the shape used is consistent with the concavity of the mating piece. Pieces 174, 176, 182, 188, and 200 can bind to a mating piece representing an atom(s) or group(s) having one hydrogen while pieces 184 and 186 are capable of binding two mating pieces representing an atom(s) or group(s) having one hydrogen.

1           Where pieces 165-200 are bound to mating piece representing a group  
2   having two hydrogens, such as another methylene  $\text{CH}_2$  piece, the convex tab 210 is  
3   preferably shaped as an equilateral triangle, but can be any shape as long as it is  
4   consistent with the concavity of the mating piece. Pieces 166, 168, 176, 180,  
5   182, 190, 192, 194, 196, and 198 have convex tabs 210 that are capable of  
6   binding to at least one mating piece representing a group having two hydrogens.  
7   Pieces 176, 180, 182, 190, 192, 194, and 198 can bind only one mating piece  
8   representing a group having two hydrogens while pieces 166, 168, and 196 can  
9   bind as many as two mating pieces representing a group having two hydrogens.

10           Methylene pieces 165-200 can also be bound to a mating piece representing  
11   a group having three hydrogens, such as methyl  $\text{CH}_3$  piece. Where a methylene  
12   piece 165-200 is bound to a mating piece representing a group having three  
13   hydrogens, the convex tab 212 is preferably shaped as a diamond; however, any  
14   shape can be used as long as it is consistent with the concavity of the mating piece.  
15   Pieces 170, 172, 178, 188, 190, 192, 194, and 200 have a convex tab 212 that  
16   can bind to mating pieces representing a group having three hydrogens and can bind  
17   to these mating pieces in one location. Piece 165 can bind to a mating piece  
18   representing a group having three hydrogens in two locations.

19           In Fig. 3 a top view of the methyl pieces  $\text{CH}_3$  214-228 of the present  
20   invention is shown. These pieces have one bonding side 230 and three curved  
21   hydrogen sides 232. Two pieces 214 and 216 are present without concavities and  
22   convex tabs and would be bonded to an atom(s) or group(s) that does not cause

splitting of the NMR peak. The remaining pieces 218-228 contain concavities and convex tabs. Table 3 illustrates the number of variations possible for the methyl pieces.

Piece Number	Number of Flat Sides with No Tabs	Number of Sides with Methine Convex Tab	Number of Sides with Methylene Convex Tab	Number of Sides with Methyl Convex Tab
214/216	1	0	0	0
218	0	1	0	0
220/224/222/228	0	0	1	0

Table 3: Methyl Pieces

There is only one type of concavity 234 present on pieces 218-228 which is preferably in the shape of a diamond; however, any shape can be used as long as it is consistent on all methyl pieces 218-228 and the convex tabs of all mating pieces.

The convex tabs on pieces 218-228 vary depending on the atom(s) or group(s) to which the pieces 218-228 are bound. Where pieces 218-228 are bound to a mating piece representing a group having one hydrogen, such as a methine piece, the convex tab 236 will preferably have three flat sides generally in the shape of a square; however, any shape can be used as long as it is consistent for the concavity of the mating piece. Piece 218 is capable of binding to one mating piece representing a group having one hydrogen.

Where methyl pieces 218-228 are bound to a mating piece representing a group having two hydrogens, such as a methylene piece, the convex tab 238 is preferably shaped as an equilateral triangle, but can be any shape as long as it is

1 consistent for the concavity of the mating piece. Pieces 220-228 have convex tab  
2 238 and are capable of binding to one mating piece representing a group having two  
3 hydrogens.

4 A methyl piece having a diamond shaped convex tab that can bind to a  
5 mating piece representing a group having three hydrogens is not present in the  
6 invention as it represents ethane which gives a singlet on the NMR spectrum.

7 Fig. 4 shows a top view of the quaternary carbon piece 250 of the present  
8 invention. This piece 250 has four flat bonding sides 251 without any concavities  
9 or convex tabs.

10 Fig. 5 is a top view of the alcohol and thiol group pieces 252-258 of the  
11 present invention. These pieces have one bonding side 260 with the remainder of  
12 the piece being preferably rounded; however, any shape is possible for this  
13 remainder side as long as it is shaped so that no other connections are possible.  
14 One piece 252 is present without concavities and convex tabs and would be bonded  
15 to an atom(s) or group(s) in which splitting is not observed. The remaining pieces  
16 254-258 contain concavities and convex tabs.

17 The concavity present on pieces 254-258 has preferably three flat inset sides  
18 generally in the shape of a square identical to the concavity mentioned for the  
19 methine pieces 103-150; however, any shape can be used as long as it is  
20 consistent on all alcohol and thiol group pieces 254-258 and with the convex tabs  
21 of all mating pieces such as, but not limited to, 208, 158 and 236.

1           The convex tabs vary depending on the atom(s) or group(s) to which the  
2 pieces are bound. Piece 254 has a convex tab 253 preferably having three flat  
3 sides generally in the shape of a square; however, any shape can be used as long as  
4 it is consistent for the concavity of the mating piece. In this case, the mating piece  
5 would be representative of a group having one hydrogen, such as a methine piece.  
6 Piece 256 has a convex tab 255 preferably being in the shape of an equilateral  
7 triangle, but can be any shape as long as it is consistent for the concavity of the  
8 mating piece. In this case, the mating piece would be representative of a group  
9 having two hydrogens, such as a methylene piece. And piece 258 has a convex tab  
10 257 preferably being in the shape of a diamond, but can be any shape as long as it  
11 is consistent for the concavity of the mating piece. In this case, the mating piece is  
12 representative of a group having three hydrogens, such as a methyl piece.

13           In Fig. 6 a top view of the amine pieces 260 – 290, 510, 512 and 514 of  
14 the present invention is shown. The quaternary amines are pieces 260, 510, 512  
15 and 514. Piece 260 has four bonding sides 292. Piece 510 has one bonding side  
16 292 and three curved hydrogen sides 511. Piece 510 is present without  
17 concavities and convex tabs and would be bonded to an atom(s) or group(s) that  
18 does not cause observable splitting of the NMR peak. Piece 510 can be modified to  
19 include the concavities and convex tabs previously discussed for the methyl pieces  
20 on the bonding side 292.

21           For piece 512 there are two bonding sides 292 and two curved hydrogen  
22 sides 511. This piece 512 is present without concavities and convex tabs and



1 would be bound to an atom(s) or group(s) that does not cause observable splitting of  
2 the NMR peak. Piece 512 can be modified to include the concavities and convex  
3 tabs previously discussed for the methylene pieces on the bonding sides 292.

4 Piece 514 has three bonding sides 292 and one curved hydrogen side 511.  
5 Piece 514 is present without concavities and convex tabs and would be bonded to  
6 an atom(s) or group(s) that does not cause observable splitting of the NMR peak.  
7 Piece 514 can be modified to include the concavities and convex tabs previously  
8 discussed for the methine pieces on the bonding sides 292.

9 The remaining amine pieces 262-290 have three sides and have the basic  
10 shape of an equilateral triangle. Piece 262, representative of a tertiary amine, has  
11 three bonding sides 294 without concavities and convex tabs and therefore would  
12 be bonded to a similar flat side since this nitrogen has no hydrogen to split its  
13 neighbor group.

14 Pieces 264-282, representative of secondary amines, contain two bonding  
15 sides 294 and one curved hydrogen side 308. Piece 264 is present without  
16 concavities and convex tabs and would be bonded to atom(s) or group(s) in which  
17 no splitting is observed. The remaining pieces 266-282 have concavities and  
18 convex tabs. Table 4 illustrates the number of variations possible for these amine  
19 pieces.

20

21

22

Piece Number	Number of Flat Sides with No Tabs	Number of Sides with Square Convex Tab	Number of Sides with Triangle Convex Tab	Number of Sides with Diamond Convex Tab
264	2	0	0	0
280	1	1	0	0
282	1	0	1	0
276	1	0	0	1
270	0	2	0	0
272	0	0	2	0
278	0	0	0	2
274	0	1	1	0
268	0	1	0	1
266	0	0	1	1

Table 4: Secondary Amine Pieces

There is only one type of concavity 298 present on these secondary amine pieces 266-282 since the concavity represents the number of splitting hydrogens on the pieces. The concavity 298 present on these pieces has preferably three flat inset sides generally in the shape of a square; however, any shape can be used as long as it is consistent on all secondary amine pieces 266-282 as well as with the convex tabs of all mating pieces.

The convex tabs vary on pieces 266-282 depending on the atom(s) or group(s) to which the piece can be bound. When the atom(s) or group(s) to which pieces 266-282 are bound has one hydrogen, the convex tab 300 will preferably have three flat sides generally in the shape of a square; however, any shape can be used as long as it is consistent for the concavity of the mating piece. Pieces 268, 270, 274, and 280 are all capable of binding to a piece representing atom(s) or group(s) with one hydrogen. Pieces 268, 274, and 280 can bind only one piece

1 representing atom(s) or group(s) with one hydrogen; whereas piece 270 can bond to  
2 two such pieces.

3 When the mating piece to which pieces 266-282 are bound represents a  
4 group having two hydrogens, the convex tab 302 is preferably shaped as an  
5 equilateral triangle; however, any shape can be used as long as it is consistent for  
6 the concavity of the mating piece. Pieces 266, 272, 274 and 282 are capable of  
7 bonding to a piece representing atom(s) or group(s) with two hydrogens. Pieces  
8 266, 274, and 282 are capable of bonding to only one piece representing atom(s)  
9 or group(s) with two hydrogens with piece 272 being capable of binding to two such  
10 pieces.

11 When the mating piece to which piece 266-282 is bound has three  
12 hydrogens, the convex tab 304 is preferably shaped as a diamond; however, any  
13 shape can be used as long as it is consistent for the concavity of the mating piece.  
14 Pieces 266, 268, 276 and 278 are capable of bonding to a piece representing  
15 atom(s) or group(s) with three hydrogens. Pieces 266, 268, and 276 are capable  
16 of bonding to only one piece representing atom(s) or group(s) with three hydrogens  
17 and piece 278 is capable of bonding two such pieces.

18 Pieces 284-290, representing primary amines, have one bonding side 306  
19 and two curved hydrogen sides 308. One piece 284 is present without concavities  
20 and convex tabs and would be bonded to an atom(s) or group(s) in which splitting of  
21 the NMR peak is not observed. The remaining pieces 286-290 contain concavities  
22 and convex tabs. Table 5 illustrates the number of variations possible for these

pieces.

Piece Number	Number of Flat Sides with No Tabs	Number of Sides with Square Convex Tab	Number of Sides with Triangle Convex Tab	Number of Sides with Diamond Convex Tab
284	1	0	0	0
290	0	1	0	0
286	0	0	1	0
288	0	0	0	1

Table 5: Primary Amine Pieces

There is only one type of concavity 310 present on these pieces 286-290 since the concavity represents the number of splitting hydrogens on these pieces.

The concavity 310 present on pieces 286-290 is preferably shaped as an equilateral triangle; however, any shape can be used as long as it is consistent for all primary amine pieces 286-290 and with the convex tabs of all mating pieces, including, but not limited to convex tabs 210, 238, 255, 160, 406, 349, 302, 314, 505, 517, 604, and 717.

The convex tabs on pieces 286-290 vary depending on the atom(s) or group(s) to which the pieces 286-290 are bound. Piece 290 is designed to bind to a piece representing atom(s) or group(s) having one splitting hydrogen. Piece 290 has a convex tab 312 having preferably three flat sides generally in the shape of a square; however, any shape can be used as long as it is consistent for the concavity of the mating piece.

Piece 286 is designed to bind to a piece representing atom(s) or group(s) having two splitting hydrogens. This piece 286 has a convex tab 314 being

1 generally in the shape of an equilateral triangle; however, any shape can be used as  
2 long as it is consistent for the concavity of the mating piece.

3 The remaining piece 288 is designed to bond to a piece representing atom(s)  
4 or group(s) having three hydrogens. Piece 288 has a convex tab 314 preferably  
5 shaped as a diamond; however, any shape can be used as long as it is consistent for  
6 the concavity of the mating piece.

7 Fig. 7 is a top view of the alkene pieces 320-342, 502, 504, 506, 516,  
8 518 and 520 of the present invention. The alkene pieces 320-342, 502, 504,  
9 506, 516, 518 and 520 are complex in that the geminal hydrogens can appear at  
10 different locations in the NMR spectrum; therefore, each piece does not necessarily  
11 represent a single carbon with all its hydrogens. Pieces 320-342, 516, 518, and  
12 520 have at least one flat bonding side 344 and may or may not have a curved  
13 hydrogen side 346. Pieces 338 and 340 are shaped as diamonds with all sides of  
14 equal length and represent alkene carbons without hydrogens. These pieces 338  
15 and 340 are present without concavities and convex tabs which indicates that these  
16 pieces do not cause observable splitting of their neighbor, so would be attached at a  
17 matching flat bonding side. Pieces 320-342, 502, 504, 506, 516, 518 and 520  
18 permit assembly of mono-, di-, tri- and tetra-substituted alkenes.

19 Pieces 320-336, 516, 518 and 520 are shaped as isosceles triangles with  
20 each piece representing one of the alkene hydrogens. These pieces have at least two  
21 flat bonding sides 344 and may or may not have one curved hydrogen side 346.  
22 Piece 520 has two flat bonding sides 344 and one curved hydrogen side 346. This

piece does not have concavities and convex tabs which indicates this piece does not cause observable splitting of its neighbor. Table 6 illustrates the number of variations possible for the remaining alkene pieces 320-336, 516, 518 and 520.

Piece Number	Number of Curved Hydrogen Sides	Number of Flat Sides with No Tabs	Number of Sides with Square Convex Tab	Number of Sides with Triangle Convex Tab	Number of Sides with Diamond Convex Tab
334/336	1	1	1	0	0
324	1	0	1	1	0
326	1	0	1	0	1
328/332	1	0	2	0	0
323	0	0	3	0	0
322	0	0	2	1	0
320	0	0	2	0	1
330	0	1	2	0	0
516	1	1	0	1	0
518	1	1	0	0	1
520	1	2	0	0	0

Table 6: Alkene Pieces

There is only one type of concavity 348 present on these remaining alkene pieces 320-336, 516, 518 and 520 since the concavity represents the number of splitting hydrogens on these pieces. The concavity 348 present on pieces 320-336, 516, 518 and 520 has preferably three flat sides generally in the shape of a square; however, any shape can be used as long as it is consistent for these pieces and with the convex tab of the mating piece.

The convex tabs on pieces 320-336, 516, 518 and 520 vary depending on the atom(s) or group(s) to which the pieces 320-336, 516, 518 and 520 are

1 bound. Pieces 320-336 are designed to bind to at least one piece representing an  
2 atom(s) or group(s) having one hydrogen. In this instance, the convex tab 347  
3 would preferably have three flat sides generally in the shape of a square; however,  
4 any shape can be used as long as it is consistent for the concavity of the mating  
5 piece. The most common piece with convex tab 347 that each of these pieces 320-  
6 336 is binding is the remaining half of the alkene molecule as dissected by a vertical  
7 plane through the molecule, but may also be any other piece representing an  
8 atom(s) or group(s) with a single hydrogen. Pieces 320-336, 516, 518 and 520  
9 can also contain convex tabs 349 where the piece is to be bound to an atom(s) or  
10 group(s) having two hydrogens. Pieces 322, 324, and 516 have a convex tab 349  
11 being generally in the shape of a triangle; however, any shape can be used as long  
12 as it is consistent for the concavity of the mating piece. Pieces 320-336, 516,  
13 518 and 520 can also contain convex tabs 321 where the piece is to be bound to  
14 atom(s) or group(s) having three hydrogens. Pieces 320, 326, and 518 have a  
15 convex tab 321 being generally in the shape of a diamond; however, any shape can  
16 be used as long as it is consistent for the concavity of the mating piece.

17 More specifically, piece 320 can bind to pieces 322, 323, and 330 due to  
18 the square concavity and convex tabs present on one bonding side as well as two  
19 other chemical fragments, one chemical fragment having one hydrogen and the  
20 other chemical fragment having three hydrogens. This piece 320 along with pieces  
21 322, 323, 328, 330, and 332 are used to make vinyl groups.

1 Piece 322 can bind to pieces 320, 323, and 330 due to the square  
2 concavity and convex tabs present on one bonding side as well as two other  
3 chemical fragments, one chemical fragment having one hydrogen and the other  
4 chemical fragment having two hydrogens.

5 Piece 323 can bind to pieces 320, 322, and 330 due to the square  
6 concavity and convex tabs present on one bonding side as well as two other  
7 chemical fragments each representative of a group having one hydrogen.

8 Piece 324 can bind to another alkene piece 320-336 due to the square  
9 concavity and convex tabs present on one bonding side. The remaining bonding  
10 side can bond a piece representing a chemical fragment having two hydrogens.

11 Piece 326 can bind to another alkene piece 320-336 due to the square  
12 concavity and convex tabs present on one bonding side. The remaining bonding  
13 side can bond a piece representing a chemical fragment having three hydrogens.

14 Pieces 328 and 332 can bind to another alkene piece 320-336 due to the  
15 square concavity and convex tabs present on one bonding side. The remaining  
16 bonding side can bond a piece representing a chemical fragment having one  
17 hydrogen.

18 Piece 330 can bond to pieces 320, 322, and 323 and can additionally bond  
19 to a third group which does not observably split the hydrogen.

20 Pieces 334 and 336 can bind to another alkene piece 320-336 due to the  
21 square concavity and convex tabs present on one bonding side. The remaining



1 bonding side can bond a piece representing a group that does not cause observable  
2 splitting of the NMR peak.

3 Piece 516 can bind a piece representing an atom(s) or group(s) having two  
4 hydrogens due to the triangular shaped convex tab 517 present on one bonding  
5 side. The remaining bonding side 515 can bond a piece representing an atom(s) or  
6 group(s) that does not cause observable splitting of the NMR peak.

7 Piece 518 can bind a piece representing an atom(s) or group(s) having three  
8 hydrogens due to the diamond shaped convex tab 519 present on one bonding side.  
9 The remaining bonding side 515 can bond a piece representing an atom(s) or  
10 group(s) that does not cause observable splitting of the NMR peak.

11 The vinyl group pieces are represented by pieces 342, 502, 504, and 506.  
12 Pieces 342 and 502-506 are shaped as a rectangle with three curved hydrogen  
13 sides 343 and one bonding side 345. Bonding side 345 can be either flat 500 as  
14 shown in piece 342 or contain concavities 501 and convex tabs 503, 505, and  
15 507 as shown for pieces 502, 504, and 506 respectively. Where concavities and  
16 convex tabs are present they indicate that these pieces would be bonded to an  
17 atom(s) or group(s) that causes observable splitting of the NMR peak.

18 Piece 502 has a bonding side 345 that contains concavity 501 and convex  
19 tab 503. Convex tab 503 is preferably shaped as a square; however, any shape can  
20 be used as long as it is consistent for the concavity of the mating piece. This piece  
21 502 would be bonded to an atom(s) or group(s) having one hydrogen.

1 Piece 504 is designed to bond to an atom(s) or group(s) having two  
2 hydrogens. Piece 504 has concavity 501 and convex tab 505. Convex tab 505 is  
3 preferably shaped as an equilateral triangle; however, any shape can be used as  
4 long as it is consistent for the concavity of the mating piece.

5 Piece 506 has a bonding side 345 that contains concavity 501 and convex  
6 tab 507. Convex tab 507 is preferably shaped as a diamond; however, any shape  
7 can be used as long as it is consistent for the concavity of the mating piece. This  
8 piece 506 would be bonded to an atom(s) or group(s) having three hydrogens.

9 Fig. 8a shows a top view of the benzene ring pieces 350-356 of the present  
10 invention. The benzene ring pieces 350-356 are represented by a large circle with  
11 one, two, three, four, five or six flat sides 358 representing mono- through hexa-  
12 substituted benzene rings. The mono-substituted piece is represented by piece 350.  
13 The relative position of the flat sides 358 indicates the relative placement of the  
14 substituents around the ring. Piece 356 represents an ortho-arrangement of  
15 substituents having two flat sides 358 at the ortho-position being 60 degrees apart.  
16 Piece 354 represents a meta-arrangement of substituents having two flat sides 358  
17 at the meta-position being 120 degrees apart. Piece 352 represents a para-  
18 arrangement of substituents having two flat sides 358 at the para-position being  
19 180 degrees apart. All flat sides 358 for benzene ring pieces 350-356 contain no  
20 concavities or convex tabs. Additional pieces can easily be envisioned representing  
21 the various tri-, tetra-, penta-, and hexa- substituted rings. The present embodiment

1 can also be extended to other aromatic and polycyclic aromatic groups such as  
2 furan, naphthalene, pyridine, and the like.

3 Alternatively, Fig 8b shows the aromatic carbons of the benzene rings  
4 represented as separate aromatic pieces 362-370, 382, and 384. These pieces are  
5 preferably shaped as equilateral triangles. Flat sides 372 represent bonding sides  
6 while curved sides 374 represent hydrogen sides. Piece 364 does not have  
7 concavities and convex tabs which indicates that this piece would be bonded to  
8 aromatic carbons or atoms without an attached hydrogen. Piece 362 has no  
9 attached hydrogens so it cannot split or be split by its neighbors. The remaining  
10 pieces 366-370, 382 and 384 contain concavities and convex tabs on the flat sides  
11 372.

12 There is one type of concavity 376 present on pieces 366-370, 382, and  
13 384 which has preferably two flat inset sides generally in the shape of a triangle;  
14 however, any shape can be used as long as it is consistent on the aromatic pieces.  
15 The convex tabs 378 used on the sides 380a and 380b are generally triangular in  
16 shape; however, any shape can be used as long as it is consistent with the concavity  
17 of the remaining aromatic pieces to which it is bound. This scheme can be  
18 extended to include polycyclic aromatic rings.

19 In Fig. 9 a top view of the aldehyde pieces 390-396 of the present invention  
20 is shown. The aldehyde pieces 390-396 have one flat side 398 and one curved  
21 hydrogen side 400. One piece 390 is present without concavities and convex tabs  
22 and would be bonded to an atom(s) or group(s) that does not cause observable

1 splitting of the NMR peak. The remaining pieces 392-396 contain concavities and  
2 convex tabs.

3 There is one type of concavity 402 present on pieces 392-396. This  
4 concavity 402 has preferably three flat sides generally in the shape of a square;  
5 however, any shape can be used as long as it is consistent on all aldehyde pieces  
6 and the convex tabs of the mating pieces, including, but not limited to, convex tabs  
7 347, 312, 208, 236, 253, 158, 615 and 705. The convex tabs on the aldehyde  
8 pieces 392-396 vary depending on the atom(s) or group(s) to which the pieces can  
9 be bound.

10 When the atom(s) or group(s) to which pieces 392-396 can be bound has  
11 one hydrogen, the convex tab 404 will preferably have three flat sides generally in  
12 the shape of a square; however, any shape can be used as long as it is consistent for  
13 the concavity of the mating piece. Piece 392 is capable of binding to a mating  
14 piece representing an atom(s) or group(s) with one hydrogen.

15 If the atom(s) or group(s) to which the piece 392-396 is bound has two  
16 hydrogens, the convex tab 406 is preferably shaped as an equilateral triangle;  
17 however, any shape can be used as long as it is consistent for the concavity of the  
18 mating piece. Piece 394 is capable of binding to a mating piece representing an  
19 atom(s) or group(s) with two hydrogens.

20 In addition, when the atom(s) or group(s) to which the piece 392-396 is  
21 bound has three hydrogens, the convex tab 408 is preferably shaped as a diamond;  
22 however, any shape can be used as long as it is consistent for the concavity of the

1 mating atom(s) or group(s). Piece 396 can bind to a piece representing an atom(s)  
2 or group(s) with three hydrogens.

3 Fig. 10 is a top view of the ketone group pieces 416-420 of the present  
4 invention. The ketone group pieces 416-420 include standard ketone piece 416,  
5 the ether piece 418, and carboxyl group 420. All ketone group pieces 416-420 are  
6 rectangular with two flat sides 417 and two curved ends 419. All pieces are  
7 present without concavities and convex tabs. Other pieces that can be included in  
8 this group with the same overall characteristics include, but are not limited to,  
9 anhydrides, ethers, esters, sulfides, sulfoxides, sulfones, and alkynes.

10 In Fig. 11 a top view of the halide piece 422 of the present invention is  
11 shown. Piece 422 has one bonding side 800 and one curved side 802. This piece  
12 422 is present without concavities and convex tabs since the halides do not cause  
13 observable splitting of the NMR peak. Other pieces that can be included in this  
14 group with the same overall characteristics include, but are not limited to, pieces for  
15 cyano and azide groups (not shown).

16 Fig. 12 is a top view of a base methyl piece 600 of another embodiment of  
17 the present invention with interchangeable tabs 602, 614 and 618. Base methyl  
18 piece 600 has a cavity defined by portions 601, 606, and 608. This cavity is  
19 designed to accept interchangeable tabs 602, 614 and 618 allowing a snug fit of  
20 portions 610, 607, and 609 of interchangeable tabs 602, 614 and 618 against  
21 portions 601, 606, and 608 of base methyl piece 600 respectively to form the final  
22 piece 605. A locking mechanism (not shown) may also be provided.

1           Final piece 605 could then substitute for piece 220 in the preferred  
2           embodiment where interchangeable tab 602 has a diamond shaped concavity 603  
3           and triangular shaped convex tab 604. Any other shape can be substituted for the  
4           concavity 603 and convex tab 604 on interchangeable tab 602 as long as the  
5           concavity 603 is consistent for all methyl pieces and the convex tab 604 is  
6           consistent for the concavity of the mating piece.

7           Where final piece 605 incorporates interchangeable tab 618 having a flat  
8           bonding side 616, it could substitute for piece 216 in the preferred embodiment.

9           Final piece 605 could also substitute for piece 218 in the preferred  
10          embodiment where interchangeable tab 614 is used having a diamond shaped  
11          concavity 603 and a square convex tab 615. Any shape can be substituted for the  
12          concavity 603 and the convex tab 615 on interchangeable tab 614 as long as the  
13          concavity 603 is consistent for all methyl pieces and the convex tab 615 is  
14          consistent for the concavity of the mating piece.

15          For purposes of this example, the base piece was selected as a methyl piece;  
16          however, any other disclosed piece could be substituted as the base piece with one  
17          or more cavities defined by portions 601, 606, and 608 that can accept  
18          interchangeable tabs defined by the respective concavities and convex tabs provided  
19          on the disclosed pieces herein.

20          Fig. 13 is a perspective view of another embodiment of the present invention  
21          showing a base methyl piece 700 with a single rotating tab member 704. Base  
22          methyl piece 700 has a cavity defined by portions 701, 702, and 703. This cavity

1 accommodates rotating tab member 704 providing for attachment points (not  
2 shown) for portion 711 of rotating tab member 704 to attach to portion 701 of base  
3 methyl piece 700 and for portion 710 of rotating tab member 704 to attach to  
4 portion 703 of base methyl piece 700. Rotating tab member 704 has four sides  
5 each defining a different bonding environment for the base methyl piece 700.  
6 Where the base methyl piece 704 is to be bonded to an atom(s) or group(s) that  
7 does not cause observable splitting of the NMR peak, flat side 709 would be rotated  
8 180 degrees to the outside or exposed bonding edge to form the final piece which  
9 could be substituted for piece 216.

10 Where the base methyl piece 700 is to be bonded to an atom(s) or group(s)  
11 that cause observable splitting of the NMR peak and this atom(s) or group(s) has  
12 only one hydrogen, such as a methine piece, side 715 of the rotating tab member  
13 704 can then be rotated if necessary (however in Fig. 13 it is already on the  
14 exposed bonding edge) to form the final piece which could substitute for piece 218.  
15 Here convex tab 705 is square shaped and concavity 706 is diamond shaped.  
16 However, any shape can be substituted for the concavity 706 and the convex tab  
17 705 as long as the concavity 706 is consistent for all methyl pieces and the convex  
18 tab 705 is consistent for the concavity of the mating piece.

19 Where the base methyl piece 700 is to be bonded to an atom(s) or group(s)  
20 that cause observable splitting of the NMR peak and this atom(s) or group(s) has  
21 two hydrogens, such as a methylene piece, side 716 of the rotating tab member  
22 704 can then be rotated 90 degrees to form the final piece which could substitute

1 for piece 220. Here convex tab 717 is triangular shaped and concavity 707 is  
2 diamond shaped. However, any shape can be substituted for the concavity 707 and  
3 the convex tab 717 as long as the concavity 707 is consistent for all methyl pieces  
4 and the convex tab 717 is consistent for the concavity of the mating piece.

5 The last side (not shown) will be used where the piece is to be bonded to an  
6 atom(s) or group(s) that cause observable splitting of the NMR peak and this  
7 atom(s) or group(s) has three hydrogens. For the base methyl piece 700 this  
8 portion of the rotating tab member 704 will not be included as such a bond would  
9 create ethane which is a singlet in the NMR spectrum. For other pieces it can be  
10 included. This last side can be rotated to form the final piece. Here both the  
11 concavity and convex tab would be shaped as a diamond. However, any shape  
12 could be used as long as the concavity is consistent for all methyl pieces and the  
13 convex tab is consistent for the concavity of all mating pieces.

14 For this example, a methyl piece was used as the base piece; however, any  
15 disclosed piece could be substituted as the base piece with one or more cavities  
16 defined by portions 701, 702, and 703 that can accept the rotating tab member  
17 704 having one flat side and three sides defined by the respective concavities and  
18 convex tabs provided on the pieces disclosed herein. The distance from the end of  
19 one convex tab to the end of the opposing convex tab located 180 degrees apart will  
20 be no greater than the thickness of the base piece. A gap will be provided between  
21 portion 702 of the base piece and the rotating tab member 704 to allow free




1 rotation of the rotating tab member. A locking mechanism (not shown) may be  
2 provided.

3       These pieces described in Figs. 1-13, along with the tested methodology,  
4 simplify NMR structural analysis for students. The students analyze each signal to  
5 determine all information present in the spectrum. During this analysis, the  
6 students determine each anticipated chemical fragment from the shift on the NMR  
7 spectrum based on the standard chemical shifts known for various chemical  
8 fragments. In addition, the students determine the splitting from the spectrum to  
9 determine the number of hydrogen neighbors that exist for a particular hydrogen or  
10 group of equivalent hydrogens. Last in the analysis is integration which gives the  
11 students information on the number of hydrogens that a given resonance represents  
12 on the NMR spectrum.

13       The analysis results in the students determining the applicable pieces of the  
14 unknown molecule. Once the pieces are known, the pieces can be put together to  
15 form the unknown molecule. Due to the interlocking nature of the pieces, the  
16 students are not able to manipulate the pieces to force them into a structure that is  
17 not consistent with the spectrum information provided. From experiments using the  
18 present NMR teaching method and apparatus, students were found to solve NMR  
19 structures in half the time compared to students who did not have the present  
20 invention. Some examples are illustrative.


EXAMPLE 1:

1.  $^1\text{H}$  NMR Spectrum for Unknown Molecule  $\text{C}_2\text{H}_5\text{Br}$ :




2. Using the Present Invention:


Peak integration is 2:3. Peak at 3.4 $\delta$  is a  $\text{CH}_2$  (from chemical shift and integration), but is next to an electronegative atom Br due to the chemical shift. Pull the halide chemical fragment piece.



The peak at 3.4 $\delta$  is also a quartet which indicates there are three adjacent neighbor hydrogens. Pull a  $\text{CH}_2$  piece that can bind to a group representing three hydrogens, i.e., one having a diamond convex tab.




The peak at 1.7  $\delta$  is a  $\text{CH}_3$  (from chemical shift and integration) and the triplet indicates an adjacent two hydrogens. Choose a  $\text{CH}_3$  piece that can bind to a group representing two hydrogens, i.e., one having a triangular convex tab.



### 3. Solving for the Unknown Molecule


The pieces may then be put together to form the molecule ethyl bromide  $\text{C}_2\text{H}_5\text{Br}$ :



### EXAMPLE 2:


#### 1. $^1\text{H}$ NMR Spectrum for Unknown Molecule $\text{C}_7\text{H}_{14}\text{O}_2$ :

300 MHz  $^1\text{H}$  NMR  
In  $\text{CDCl}_3$





2. Using the Present Invention:

There is a heptet at 5.0  $\delta$  having one hydrogen (from integration). Begin to look for a CH piece. The chemical shift indicates this component is next to an oxygen. Chose an oxygen piece. The splitting into the heptet indicates this component is next to six neighbor hydrogens. Choose a CH piece that can bind to six hydrogens i.e. two methyl groups.




There is a triplet at 2.2 $\delta$  which has two hydrogens (from integration). Begin looking at the CH<sub>2</sub> pieces. The chemical shift indicates this component is next to a carbonyl. Select a ketone piece. The triplet indicates this component is next to two neighbor hydrogens. Select a CH<sub>2</sub> piece which can bind to a component having two hydrogens i.e. a piece having the triangular convex tab.




There is a hexet at 1.6 $\delta$  having two hydrogens (from integration). The chemical shift indicates an alkyl group. The hexet indicates this component is next to five neighbor hydrogens, three on one side, and two on the other. Select the


appropriate  $\text{CH}_2$  piece having a triangular convex tab on one side and a diamond convex tab on the other.



There is a doublet at 1.2 $\delta$  with six hydrogens (from integration). The chemical shift indicates it is an alkyl group. The doublet indicates it's next to one neighbor hydrogen. This must represent two equivalent  $\text{CH}_3$  groups (since six hydrogens are involved) each next to a component having one hydrogen i.e. next to a component having a square convex tab. Select two  $\text{CH}_3$  pieces having a square convex tab.




There is a triplet at 0.9 $\delta$  having three hydrogens (from integration). The chemical shift indicates it's an alkyl group. The triplet indicates this group is next to two neighbor hydrogens. Select a  $\text{CH}_3$  piece with a triangular convex tab representing the neighboring component with two hydrogens.



3. Solving for the Unknown Molecule:


Assemble pieces, making sure to use all pieces and take into account chemical shift information. The pieces can be put together to form isopropyl butyrate,  $C_7H_{14}O_2$ .



EXAMPLE 3:


1.  $^1H$  NMR Spectrum for Unknown Molecule  $C_4H_9Cl$ :

While this spectrum has fewer peaks than EXAMPLE 2, it is frequently more difficult for students due to the complex multiplet signal at 1.75  $\delta$ . Students often feel that this makes the spectrum impossible since one cannot determine the number of hydrogens adjacent to this hydrogen.




## 2. Using the Present Invention:

There is a hextet at 4.0 $\delta$  that has one hydrogen (from integration). The chemical shift indicates this group is adjacent to an electronegative Cl. Select a Cl piece. The hextet indicates this group is also next to five neighbor hydrogens. Select a CH piece that can bind to five hydrogens i.e. a CH piece having two different convex tabs—one that can bind to two hydrogens (triangular convex tab) and one that can bind to three hydrogens (diamond convex tab).




1        There is a multiplet at 1.75 $\delta$  that has two hydrogens (from integration).  
2        Begin looking at the alkyl CH<sub>2</sub> pieces, but at this point one cannot tell about the  
3        neighbor hydrogens other than there are several.

4        There is a doublet at 1.5 $\delta$  which has three hydrogens. The chemical shift  
5        indicates it is an alkyl group while the doublet indicates this group is next to one  
6        neighbor hydrogen. Select a CH<sub>3</sub> piece that has a square convex tab.





12       There is a triplet at 1.0 $\delta$  that has three hydrogens. The chemical shift  
13       indicates it is an alkyl group. The triplet indicates that it is next to two neighbor  
14       hydrogens. Select a CH<sub>3</sub> piece having a triangular convex tab representative of a  
15       neighboring component having two hydrogens.




### 22       3. Solving for the Unknown Molecule:

24       Put the known pieces together. Notice that once the known pieces are  
25       assembled the undetermined CH<sub>2</sub> piece is obvious from the neighbor pieces which  
26       must bond to it as follows:





Undetermined  $\text{CH}_2$  piece



The final structure is therefore determined to be sec-butyl chloride,  $\text{C}_4\text{H}_9\text{Cl}$ .


#### EXAMPLE 4:

##### 1. $^1\text{H}$ NMR Spectrum for Unknown Molecule $\text{C}_{13}\text{H}_{16}\text{O}_3$ :


This spectrum is very complex. Such spectra are typically solved along with Infrared Spectra which help determine which chemical fragments are present in the molecule. This molecule is extremely difficult to identify using the "look, see, guess" method in which students solve the spectrum by guessing chemical structures.

Using this approach there are two recognizable groups: a di-substituted aromatic ring at 6.8-7.8 $\delta$ , and an isolated ethyl group at 2.5 $\delta$ , 1.0 $\delta$ . Further analysis using the present invention, however, demonstrates that the quartet/triplet pattern of the

ethyl group is in fact not correct. This molecule has no isolated ethyl group. Such misidentifications using the "look, see, guess" method are a common occurrence in complex spectra such as this and make the "look, see, guess" method a very poor approach for solving complex spectra.



Infrared spectrum, liquid thin film (courtesy of SDBSWeb:  
<http://www.aist.go.jp/RIODB/SDBS/> (2003))



## 2. Using the Present Invention:

Initial analysis of the NMR and IR data are similar in both existing methods and the method of the present invention. The band at 10.8  $\delta$  could be either a carboxylic acid or phenol. Analysis of the liquid thin film infrared spectrum indicates it is a phenol due to the lack of extensive OH hydrogen bonding at 2500-3300  $\text{cm}^{-1}$ .


Acyclic alkanes have the general formula  $\text{C}_n\text{H}_{2n+2}$  while cyclic alkanes and alkenes have the generally formula  $\text{C}_n\text{H}_{2n}$ . The degree of unsaturation of the molecule is calculated by determining the number of hydrogens for the corresponding saturated alkane and subtracting the number of hydrogens actually present and dividing by two. The present molecule has thirteen carbons so the number of hydrogens for the corresponding saturated alkane would be  $(2n+2)$  or

28. Oxygen atoms are ignored. Subtracting out the number of hydrogens actually present (16) means there are twelve hydrogens missing compared to a totally saturated molecules.

The degree of unsaturation is determined by dividing this number by two. This indicates there are  $12/2 = 6$  double bonds and/or rings in the molecule. The NMR and IR indicate the presence of an aromatic ring (4 unsaturations), a carbonyl group (1 unsaturation); thus the two alkene hydrogens observed in the NMR must be on a single double bond (1 unsaturation). Finally the combination of three oxygens in the molecule, the presence of a phenol and carbonyl (IR at  $1680\text{ cm}^{-1}$ ) and the strong IR bands at  $1200\text{-}1300\text{ cm}^{-1}$  indicate that the molecule contains an ester functionality. Select the ester piece 420.

## 2. Using the Present Invention:

There is a singlet at  $10.8\delta$  with one hydrogen (from integration). This is due to a carboxylic acid or alcohol (phenol). Analysis of the liquid thin film infrared spectrum indicates it is a phenol due to the lack of extensive OH hydrogen bonding at  $2500\text{-}3300\text{ cm}^{-1}$ . Select an OH piece.




There is a doublet at  $7.8\delta$  with one hydrogen (from integration). This is an aromatic hydrogen with one neighbor hydrogen. Select an aromatic piece having

one neighbor hydrogen i.e. having one triangular concavity and one triangular convex tab.



There is a triplet at 7.4 $\delta$  with one hydrogen (from integration). This is an aromatic hydrogen with two neighbor hydrogens. Select an aromatic piece with two sets of triangular concavities and convex tabs.




There is a doublet at 7.0 $\delta$  with one hydrogen (from integration). This is another aromatic hydrogen with one neighbor hydrogen. Select another aromatic piece with one triangular concavity and one triangular convex tab.




There is a triplet at 6.8 $\delta$  with one hydrogen (from integration). This is another aromatic hydrogen with two neighbor hydrogens. Select an aromatic piece

1 with two sets of triangular concavities and convex tabs.




2  
3  
4  
5  
6  
7  
8 The presence of only four aromatic hydrogens indicates that there are two  
9 aromatic carbons without any attached hydrogens. The pieces below represent such  
10 pieces.



11  
12  
13  
14  
15  
16 There is a quartet at 5.6 $\delta$  with long range splitting having one hydrogen.


17 This is an alkene hydrogen with three neighbor hydrogens. Since there are two  
18 alkene hydrogens (see the 5.4 $\delta$  peak) and a single alkene double bond, this must be  
19 a di-substituted alkene connected to a CH<sub>2</sub> group. The piece below represents such  
20 a piece.




21  
22  
23  
24  
25  
26  
27 There is a quartet at 5.4 $\delta$  with long range splitting having one hydrogen.

28 This is an alkene hydrogen with three neighbor hydrogens. Since there are two  
29 alkene hydrogens (see the 5.6 $\delta$  peak) and a single alkene double bond, this must be  
30 a di-substituted alkene connected to a CH<sub>2</sub> group. The piece below represents such


1 a piece.




9 There is a triplet at 4.3 $\delta$  with two hydrogens (from integration). The  
10 chemical shift indicates that these two hydrogens are adjacent to an oxygen. The  
11 triplet splitting indicates this group has two neighbor hydrogens. Select a CH<sub>2</sub> piece  
12 with a triangular convex tab for connection to a piece having two hydrogens.




20 There is a quartet at 2.5 $\delta$  having two hydrogens (from integration). The  
21 chemical shift indicates that these two hydrogens are adjacent to a carbonyl or  
22 alkene. The quartet splitting indicates this group is next to three neighbor  
23 hydrogens. Select a CH<sub>2</sub> piece having a diamond convex tab for connection to a  
24 piece having three hydrogens.



1  
2        There is a pentet at 2.1 $\delta$  having two hydrogens (from integration). The  
3 chemical shift indicates that these two hydrogens are adjacent to a carbonyl or  
4 alkene. The pentet indicates that the present group is next to four neighbor  
5 hydrogens. Since there are four neighbor hydrogens, it is impossible for the group to  
6 be next to a carbonyl, so it must be next to the alkene. Select a CH<sub>2</sub> piece having a  
7 square convex tab for connection to a piece having one hydrogen and a diamond  
8 convex tab for connection to a piece having three hydrogens.




17        There is a triplet at 1.0 $\delta$  having three hydrogens (from integration). The  
18 chemical shift indicates these three hydrogens are on an alkyl group. The triplet  
19 indicates that this component has two neighbor hydrogens. Select a CH<sub>3</sub> piece  
20 having a triangular convex tab representative of a component having two hydrogens.





1 3. Solving for the Unknown Molecule:  
2  
3

4 a) Aromatic ring:  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23



1           There are problems in the first attempt to put the molecule together. See Fig.  
2 14A. There are two pieces which can bond to the piece 228 and no part to connect  
3 the alkene and aromatic chemical fragments. This indicates that the splitting has  
4 been misinterpreted. There is not an isolated ethyl group. The methylene quartet at  
5 2.5  $\delta$  must not be adjacent to a methyl, but rather two hydrogens on one side and a  
6 single hydrogen on the other. Replacement of piece 178 with piece 176 allows  
7 completion of the molecule. See Fig. 14B.

8           In accordance with the principles of the present invention, the functionality  
9 disclosed herein can not only be implemented manually, but can be implemented by  
10 hardware, software, and/or a combination of both. Software implementations can be  
11 written in any suitable language or a combination of languages where applicable,  
12 including fourth generation languages defined as programming languages closer to  
13 human languages than typical high level (third generation) programming languages.  
14 Most fourth generation languages are used to access databases. The software  
15 implementation can also be written in a third generation languages such as, but not  
16 limited to, Ada, Algol, BASIC, COBOL, C, C++, FORTRAN, LISP, Pascal, and  
17 Prolog. These third generation languages are known as high level programming  
18 languages and are defined as enabling a programmer to write programs that are  
19 more or less independent of a particular type of computer. These languages are  
20 considered high-level because they are closer to human languages and further from  
21 machine languages.

1       The software used in the invention can also be written in a second generation  
2 language or assembly language. Assembly language is a programming language  
3 once removed from a computer's machine language. This language has the same  
4 structure and set of commands as machine languages, but enables a programmer to  
5 use names instead of numbers.

6       It is rare, but possible that the present software will incorporate first  
7 generation language or machine language. Machine language is the only language  
8 understood by computers. While easily understood by computers, machine  
9 languages are almost impossible for humans to use because they consist entirely of  
10 numbers. Programs written in high-level languages are translated into assembly  
11 language or machine language with a compiler or interpreter. Assembly language  
12 programs are translated into machine language with an assembler program.

13       The system running such a software program would have a standard  
14 computer subsystem, such as the IBM personal computer (also known as the IBM  
15 PC), including a CPU (e.g. a microcomputer system, including a central processing  
16 unit, disk drive, etc.), a display device (such as a standard CRT monitor or television  
17 monitor), an input device (such as a keyboard or mouse), an application specific  
18 piece of hardware, or other suitable device. It is preferred that the computer  
19 subsystem incorporate a graphical user interface operating system such as, but not  
20 limited to, Mac OS/System, UNIX or Windows. Additional functions that are  
21 preferred, but not required from the operating system include multi-user capability,  
22 multiprocessing, multitasking, and multithreading.

1 In addition to using discrete hardware components in a logic circuit, the  
2 required logic may also be performed by an application specific integrated circuit  
3 ("ASIC"), a programmed programmable logic device ("PLD"), or other device. The  
4 system will also include various hardware components which are well known in the  
5 art, such as connectors, cables, and the like. Moreover, at least part of this  
6 functionality may be embodied in computer readable media (also referred to as  
7 computer program products), such as magnetic, magnetic-optical, and optical  
8 media, used in programming an information-processing apparatus to perform in  
9 accordance with the invention. This functionality also may be embodied in computer  
10 readable media, or computer program products, such as a transmitted waveform to  
11 be used in transmitting the information or functionality.

12 The software/ hardware program of the present invention can include a  
13 student tutorial application and/or a laboratory identification application. In both  
14 applications, a series of user interface screens will be displayed. These screens  
15 illustrate what the user sees when participating in the student tutorial application or  
16 laboratory identification application respectively. It will of course be understood that  
17 the application of the present invention to a software or hardware program is not  
18 restricted to the particular user interfaces illustrated. Rather, any suitable user  
19 interface can be employed.

20 The student tutorial application will be discussed first. In the student tutorial  
21 application, the initial configuration screen will appear which includes a plurality of  
22 check boxes or the like through which the student user can select which application

1 functions he or she wishes to explore. These check boxes are selected and  
2 deselected by selective mouse clicks. The actual items listed on the configuration  
3 screen correspond to application functions specific to the program, such as, but not  
4 limited to skill level, molecule type, and random sort.

5       After the student user has selected the desired functions, the OK button on  
6 the screen is clicked, whereupon the chosen testing sequence begins. The testing  
7 sequence begins in the next window, the selection screen, which provides an NMR  
8 spectrum. The student user is then prompted at the selection screen to select atoms  
9 or groups from the screen to begin the identification. These atoms and groups are  
10 labeled on descriptive buttons provided on the screen. These atom and group  
11 buttons are selected and deselected by selective mouse clicks. Upon each selection  
12 of the atom or group, the respective atom or group appears on the screen as a larger  
13 and moveable component on the screen.

14       When the student user has selected all atoms and/or groups he or she  
15 believes are applicable, the OK button on the screen is clicked. The student user is  
16 then prompted in the arrangement screen to select between buttons that display  
17 such functions as auto-arrange and manual arrange. These buttons are selected by  
18 mouse clicks. Upon selection of auto-arrange, the selected atom and/or group  
19 pieces are automatically arranged on the computer screen to provide the best fit or a  
20 series of applicable fits between the chosen atom and/or group pieces. Selection of  
21 manual arrange simply allows the student user to move the atom and/or group  
22 pieces on the screen himself to obtain a perfect fit. If a perfect fit cannot be found,

1 the student user will be prompted to return to the selection screen to try again, to try  
2 another molecule, or to see the answer.

3       If a perfect fit is found between the chosen atom and/or group pieces, an  
4 exclamation on the screen will appear such as, but not limited to, "Perfect Fit". If a  
5 perfect fit is found, the student user is then prompted by an open box to write the  
6 name of the unknown molecule. If the name keyed into the open box by the student  
7 user is the identity of the unknown molecule, an exclamation will appear on the  
8 screen, such as, but not limited to, "Congratulations, you've identified the unknown  
9 molecule". The student user can then be prompted to select between buttons that  
10 display functions such as, but not limited to, "Try Another", "View 3D", and "View  
11 MSDS". These buttons are selected by mouse clicks.

12       If the name keyed into the open box by the student user is not the identity of  
13 the unknown molecule, an exclamation will appear on the screen such as, but not  
14 limited to, "Oops, try again". The student user will then be returned to the selection  
15 screen and prompted to select between buttons that allow the student user to decide  
16 whether to change the existing selection or start a new selection of atoms and/or  
17 groups. The buttons are selected by mouse clicks. Once the student user has  
18 entered the new atoms and/or groups, again the student user can choose to auto  
19 arrange the pieces in the arrangement screen and determine if a perfect fit exists.  
20 The student user can again type in the applicable name to determine if he or she  
21 has correctly identified the molecule.

1           The application can be preconfigured at the configuration screen to repeat  
2 continuously until the right answer is obtained or to repeat for only a pre-designated  
3 number of times before the student user is prompted with the correct identification  
4 and atom and/or group arrangement of the unknown molecule. With each wrong  
5 name entered, the student user will be prompted to select between buttons that  
6 display functions such as, but not limited to, "Try Another" and "See Answer".  
7 These buttons can be selected by mouse clicks.

8           The laboratory identification application can exist independently, with the  
9 student tutorial application or associated with the computer system of an NMR  
10 instrument in a laboratory. In the laboratory identification application, an initial  
11 configuration screen will appear which includes a plurality of checkboxes or the like  
12 through which the laboratory user can select which application functions he or she  
13 wishes to explore. The check boxes are selected and deselected by selective mouse  
14 clicks. The actual items listed on the configuration screen correspond to application  
15 functions specific to the program, such as, but not limited to scan spectrum, run  
16 spectrum and enter peaks.

17           After the laboratory user has selected the desired functions, the OK button is  
18 clicked on the screen, whereupon the chosen function begins. The scan spectrum  
19 function begins in the next window which shows the NMR spectrum image being  
20 scanned onto the screen from a paper copy. The spectrum could also be transferred  
21 directly from the spectrometer acquisition program. The laboratory user is then  
22 prompted with various formatting functions such as clarifying the image. Once the

1 desired image is obtained from the formatting, the laboratory user can then select a  
2 button on the screen such as "Accept Image".

3       Once the laboratory user has accepted the NMR spectrum image from the  
4 paper scan, the laboratory user is then prompted at a selection screen to select  
5 atoms and/or groups from the screen to begin identification. These atoms and  
6 groups are labeled as descriptive buttons provided on the screen. These atom and  
7 group buttons are selected and deselected by selective mouse clicks. Upon each  
8 selection of the atom or group, the respective atom or group appears on the screen  
9 as a larger and moveable component on the screen.

10       When the laboratory user has selected all atoms and/or groups he or she  
11 believes are applicable, the OK button on the screen is clicked. The laboratory user  
12 is then prompted in the arrangement screen to select between buttons that display  
13 such functions as auto arrange and manual arrange. These buttons are selected by  
14 mouse clicks. Upon selection of auto-arrange, the selected atom and/or group  
15 pieces are automatically arranged on the computer screen to provide the best fit or  
16 series of applicable fits between the chosen atom and/or group pieces. Selection of  
17 manual arrange simply allows the laboratory user to move the atom and/or group  
18 pieces on the screen himself to obtain a perfect fit. If a perfect fit cannot be found,  
19 the laboratory user will be prompted to return to the selection screen to try again or  
20 to access the built in NMR spectrum database to obtain the identity of the molecule  
21 or a series of possible identities by randomly choosing suspected possibilities.



1           If a perfect fit is found between the chosen chemical fragment pieces, an  
2 exclamation on the screen will appear such as, but not limited to, "Perfect Fit". If a  
3 perfect fit is found, the laboratory user is then prompted by an open box to write the  
4 name of the unknown molecule. A button is also provided on the screen that upon  
5 selection by the laboratory user allows the program to automatically provide a name  
6 for the unknown molecule or a list of possibilities. Once the name is entered by  
7 either means, the program will then search within the built in NMR spectrum  
8 database to determine if a spectrum for the suspected molecule is contained therein.  
9 If one exists, the NMR spectrum will be displayed on the screen in the same window  
10 as the scanned NMR spectrum image so the laboratory user or the program can  
11 perform a comparison of the spectra. The laboratory user can then be prompted to  
12 select between buttons that display functions such as, but not limited to, "Scan  
13 Another", "View 3D", and "View MSDS". These buttons are selected by mouse  
14 clicks.

15           If the laboratory user is not satisfied with the search results, the laboratory  
16 user can select from buttons on the screen that prompt the laboratory user to return  
17 to the selection screen to try again with a new selection of atoms and/or groups or to  
18 access the built in NMR spectrum database to obtain the identity of the molecule or  
19 a series of possible identities by randomly choosing suspected possibilities.  
20 Alternatively, the program may search the database to find similar spectra by  
21 matching the peaks. This is common in commercial infrared and mass spectrometer

1 instruments. The laboratory user can also return to the open box and type in names  
2 similar to the suspected name of the unknown molecule.

3 If the laboratory user decides to try again at the selection screen, the  
4 laboratory user will again enter possible atoms and/or groups. Once the laboratory  
5 user has entered the new atoms and/or groups, again the laboratory user can choose  
6 to auto arrange the pieces in the arrangement screen and determine if a perfect fit  
7 exists. The laboratory user can again type in the applicable name to access an NMR  
8 spectrum from the built in NMR spectrum database.

9 When a laboratory user selects the run spectrum function, the application  
10 launches into the applicable software program provided with the NMR instrument  
11 from the manufacturer and/or supplier of NMR spectrometers. Since the laboratory  
12 user will be interfaced into this second software program, the screens that appear  
13 from this point in this second software program are the proprietary materials of  
14 those respective companies.

15 When a laboratory user selects the enter peaks function button, this function  
16 is launched onto the screen prompting the laboratory user to enter the chemical shift  
17 for peaks on the NMR spectrum, integration if known, and the splitting. Once the  
18 laboratory user has entered the peak information, a cursory NMR spectrum will  
19 appear on the screen. The laboratory user is prompted with buttons to select  
20 whether this NMR spectrum is correct. The buttons are selected by mouse clicks.

21 Once the laboratory user has approved the NMR spectrum on the screen, the  
22 laboratory user is then prompted at a selection screen to select atoms and/or groups

1 from the screen to begin identification. These atoms and groups are labeled as  
2 descriptive buttons provided on the screen. These atom and group buttons are  
3 selected and deselected by selective mouse clicks. Upon each selection of the atom  
4 or group, the respective atom or group appears on the screen as a larger and  
5 moveable component on the screen.

6 When the laboratory user has selected all atoms and/or groups he or she  
7 believes are applicable, the OK button on the screen is clicked. The laboratory user  
8 is then prompted in the arrangement screen to select between buttons that display  
9 such functions as auto arrange and manual arrange. These buttons are selected by  
10 mouse clicks. Upon selection of auto-arrange, the selected atom and/or group  
11 pieces are automatically arranged on the computer screen to provide the best fit or  
12 series of applicable fits between the chosen atom and/or group pieces. Selection of  
13 manual arrange simply allows the laboratory user to move the atom and/or group  
14 pieces on the screen himself to obtain a perfect fit. If a perfect fit cannot be found,  
15 the laboratory user will be prompted to return to the selection screen to try again or  
16 to access the built in NMR spectrum database to obtain the identity of the molecule  
17 or series of possible identities by randomly choosing suspected possibilities.

18 If a perfect fit is found between the chosen atom and/or group pieces, an  
19 exclamation on the screen will appear such as, but not limited to, "Perfect Fit". If a  
20 perfect fit is found, the laboratory user is then prompted by an open box to write the  
21 name of the unknown molecule. A button is also provided on the screen that upon  
22 selection by the laboratory user allows the program to automatically provide a name

1 for the unknown molecule or a list of possibilities. Once the name is entered by  
2 either means, the program will then search within the built in NMR spectrum  
3 database to determine if a spectrum for the suspected molecule is contained therein.  
4 If one exists, the NMR spectrum will be displayed on the screen in the same window  
5 as the cursory image so the laboratory user or the program can perform a  
6 comparison of the spectra. The laboratory user can then be prompted to select  
7 between buttons that display functions such as, but not limited to, "Enter Another",  
8 "View 3D", and "View MSDS". These buttons are selected by mouse clicks.

9       If the laboratory user is not satisfied with the search results, the laboratory  
10 user can select from buttons on the screen that prompt the laboratory user to return  
11 to the selection screen to try again with a new selection of atoms and/or groups or to  
12 access the built in NMR spectrum database to obtain the identity of the molecule or  
13 a series of possible identities by randomly choosing suspected possibilities. The  
14 laboratory user can also return to the open box and type in names similar to the  
15 suspected name of the unknown molecule.

16       If the laboratory user decides to try again at the selection screen, the  
17 laboratory user will again enter possible atoms and/or groups. Once the laboratory  
18 user has entered the new atoms and/or groups, again the laboratory user can choose  
19 to auto arrange the pieces in the arrangement screen and determine if a perfect fit  
20 exists. The laboratory user can again type in the applicable name to access an NMR  
21 spectrum from the built in NMR spectrum database.

1        If the name is not found in the NMR spectrum database, the user will be  
2 notified and any final structural identification will be limited to the identification  
3 found during the "Perfect Fit".

4        Although the invention has been described with reference to specific  
5 embodiments, this description is not meant to be construed in a limited sense.  
6 Various modifications of the disclosed embodiments, as well as alternative  
7 embodiments of the inventions will become apparent to persons skilled in the art  
8 upon the reference to the description of the invention. Accordingly it is intended  
9 to embrace all such alternatives, modifications and variations as fall within the  
10 spirit and broad scope of the invention. It is, therefore, contemplated that the  
11 appended claims will cover such modifications that fall within the scope of the  
12 invention.